

Westravelle Analytical Ltd, a Tarnovell company

ANALYTICAL AND STABILITY SERVICES

Service catalogue 2025

Westravelle Analytical Ltd, a Tarnovell company, York

Document WA-CAT-2025 Rev 01 | QA approved 12/06/2025 | Owner: Head of Analytical Services

1. ABOUT WESTRAVELLE

1.1 Westravelle provides analytical chemistry and stability testing for small-molecule drug substances and drug products, from early development to registration batches. 1.2 Every study runs under a numbered protocol, with batch identity, packaging and storage recorded at each step. 1.3 Our reports state results within the tested interval; shelf-life and specification decisions remain with the client.

2. ICH CHAMBER PROGRAMME

Table 1 Storage conditions

Condition	Use	Typical pull points (months)
25 °C/60% RH	Long term	0, 3, 6, 9, 12, 18, 24, 36
30 °C/65% RH	Intermediate	0, 3, 6, 9, 12
30 °C/75% RH	Zone IVb long term	0, 3, 6, 9, 12, 18, 24
40 °C/75% RH	Accelerated	0, 1, 3, 6
5 °C ± 3 °C	Refrigerated	0, 3, 6, 9, 12, 18, 24
Photostability	ICH Q1B option 2	Single exposure with dark control

2.1 Chambers are temperature- and humidity-mapped annually and monitored continuously with independent alarms. 2.2 Excursions are investigated and reported to the client as deviation notes with an impact assessment.

3. STABILITY PULLS AND TESTING

- 3.1 Pulls within ±7 days of the nominal date up to 12 months and ±14 days thereafter
- 3.2 Tests by protocol: appearance, assay, related substances, water (KF), dissolution, microbial limits by arrangement
- 3.3 Data summary issued within 15 working days of each pull; out-of-specification results phoned through within one working day

4. METHOD VALIDATION AND QUALIFICATION

Table 2 Validation scope

Method type	Characteristics (ICH Q2(R2))
Assay	Specificity, linearity and range (80-120%), accuracy, repeatability, intermediate precision
Quantitative impurities	Specificity incl. forced degradation, linearity from LOQ, accuracy at LOQ and specification, precision, LOQ, robustness
Limit tests	Specificity and detection limit
Early-phase qualification	Reduced set agreed per protocol: specificity, linearity, repeatability, LOQ for specified impurities

5. METHOD TRANSFER

- 5.1 Prerequisites: validated or qualified method, method history, reference standards with certificates, representative batch
- 5.2 Comparative testing on one or two batches with pre-agreed acceptance criteria
- 5.3 Transfer report signed by both laboratories before stability use

6. SAMPLE PLANNING

6.1 Quantities are calculated per protocol from the tests at each pull, plus 10% contingency. Example for a capsule product on three conditions for 12 months:

Table 3 Example unit requirements

Test per pull	Units
Assay and related substances	10 capsules
Water (KF)	5 capsules
Dissolution	12 capsules
Appearance	from the above
Total per pull	27 capsules

7. SUBMITTING SAMPLES

- 7.1 Stability lots in final packaging with batch certificate and packaging description
- 7.2 Reference standards and impurity markers with certificates of analysis
- 7.3 Completed sample submission form (WA-F-021) and shipping conditions
- 7.4 Hazard information and any controlled-substance licences

8. REPORTING

8.1 Interim reports at agreed time points; final reports with trend tables and plots against specification. 8.2 Conclusions stay within the tested interval; extrapolation and shelf-life proposals are the client's decision.

9. GROUP SERVICES AND ENQUIRIES

9.1 Formulation support is available from Durnesswick Laboratories and DMPK from Merrivoss Bioanalysis, both Tarnovell companies; ask your Westravell contact for a joint proposal. 9.2 Enquiries: Dr A. Penrose, Head of Analytical Services, Westravell Analytical Ltd, York.